


Daisy-Chain DAB Card

+Vcc = 5V (PO b12)



E15
C14
S15
S14

z 14 or ↓ 14
PO b13

z 15 or ↓ 15

PO z 13

Slot 4

Strap.	connected	connected
	11	13
	E9	D9
	E10	D10.

41mm

Ewald
14/02/2006

