


COLLIMATOR BA5 Beam Loss installation



SEM 1	ch 1
BL 1	ch 2
BL 2	ch 3
BL 3	ch 4
BL 4	ch 5
BL 5	ch 7
BL 6	ch 8